

Yoga Installation - SolaRay Heaters

Install according to the [Customer and Contractor Checklist - Installation/Operation](#)

Below are the resources for the [SolaRay](#) panel themselves:

- [Manufacturers Installation Instructions & Full Specifications](#)
- [Schematic of Sola-Ray Heating Panel](#)
- [Installation Slideshow](#)
- [Installation Videos](#)
- [Installation Manual](#)

Here are our infrared hot yoga support guides. More information can be found on our [Support Hub](#):

- [Ecobee Wiring Diagrams](#)
- [Infrared Yoga Installation Guide](#)
- [Heating Green Infrared Yoga Operation Guide](#)

Relays: Each relay should have its own dedicated circuit and control a group of heaters

- The total amperage of the panels (wattage/volts= amps) should not exceed 80% of the amperage of the relays (ex: 30 amp relays should not exceed 24 amps in regards to the number of heaters)
- We recommend placing relays in an accessible area such as near the electrical panel so they can be accessed easily to confirm they are working properly.

Please see our [Infrared Yoga Support Page](#) linked, including our [Infrared Yoga Installation Guide](#), [Ecobee Wiring Diagram](#), [Operation Guide](#) for additional installation support.

If your electrician has any questions about wiring the controls (thermostat, relays, transformer) they can reach out directly to the [Professional Technical Support Line at Jackson Systems 1-888-652-9663](#). They are available 8 AM - 6 PM EST M-F.

